

animalarm Quick Start



Base Station



Remote Sensor

1. If the batteries are not inserted in your animalarm base station and remote sensor please insert the batteries provided.
2. Switch on your animalarm base station by pressing and holding the power key for 2-3 seconds. The remote sensor will automatically switch on when the batteries are inserted.
3. Enter 'Settings' and tap the screen as instructed.
4. Go to 'Sensors' to add your remote sensor. If the sensor ID is not displayed press the remote sensor power key 5 times in 10 seconds. The sensor ID will then be displayed as available to be 'Paired'. Select the sensor ID and move to 'Paired' by selecting the right arrow.
5. You will receive a 'Welcome Email' with a link to your personal customer portal. Follow the link and setup your user information and notification preferences online.
6. When you have added your user details you will receive a 'New User' notification if you have selected text or email. If you have selected to use the portal add a quick link to the Home Screen on your phone.
7. We recommend that you charge your animalarm base station as the battery might not be fully charged.
8. For full instructions please refer to the animalarm User Manual or go to www.theanimalarm.com